



INSTALLATION INSTRUCTIONS

**VOLVO - 940 (1992 - 95)
VOLVO - 740 WAGON (1992)**

PART NUMBER: VO-52-92

**VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screw driver or a T-20 Torx driver, hook tool.

PARTS INCLUDED: Pro.Fit VSM™, instructions.

LOCATION: To the right of the climate control.

STEP 1.

Begin by removing the trim bezel which covers the climate control. Insert the hook tool behind upper right corner of the trim bezel that surrounds the climate control. Pull toward you to release clip. Grasp the right end of the bezel and **carefully** work the bezel loose releasing a series of clips. The bezel extends over to the right of the steering column. Let the bezel hang. Remove two (2) screws to right side of climate control using either the #2 Phillips screwdriver or the Torx driver depending on which type of screws you have.



STEP 2.

Attach the phone holder to the Pro.Fit VSM™. Position mount over the right side of climate control aligning the two (2) screw holes. Replace original factory screws and tighten.



STEP 3.

Re-assemble the dash in reverse order securing all clips.

This completes the installation of your Pro.Fit VSM™.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© Pro.Fit International, Eagan, MN 2003